

Problem Hearing the Caller or Vice Versa

This is usually resolved by re-seating the handset cable. Unplug the curly cord, from the handset and back of the phone and then plug both ends back in.